




A	F308A	1X
	Part no	No of items

B	F521	6X
	Part no	No of items

C	FS544	1X
	Part no	No of items



D	F310A	2X
	Part no	No of items

E	F310B	2X
	Part no	No of items

F	F310CL	1X
	Part no	No of items

G	F310CR	1X
	Part no	No of items

H	F310D	2X
	Part no	No of items

M-R3015M8S
2X



M-460641BF
2X



rubber

M-460641D
12X



rubber

M-460641AY
12X



rubber end caps

M-460641AL
12X



plastic end caps

M-R3015M835S
2X



M-SR4025M820S
2X



M-R3015M610S
2X




M-VBM8x30S
2X



M-VBM8x25S
2X




STEP 1



M-460641AY
12X

rubber end caps


STEP 2



M-460641AL
12X


plastic end caps

STEP 3




M-R3015M610S
2X

STEP 4




STEP 5




M-460641D
12X

rubber

STEP
6



STEP
7



STEP
8

